

02/2014

Mod: DDW-2

Production code: HDW2



Diamond
catering equipment


Drawer Warmers

HDW Series

HDW-1

HDW-2

HDW-3



Replacement Parts List

DRAWER WARMERS

HDW-X, HDW-XB, HDW-XN, and HWB-XNB Models




Use of replacement parts other than those supplied by Hatco Corporation may result in damage to the unit or injury to personnel and will void all warranties.

Model Designation

H D W - X B

B = Built-In
N = Narrow
Quantity of Drawers
Heated Drawer Warmer



PARTS COMMON TO ALL HDW MODELS

Item	Description	Part No.	Qty.
1	Heat Baffle Assembly, Standard	R04.16.519.00	1-4
	Heat Baffle Assembly, Narrow	04.16.725.00	1-3
2	Pan, Full Size, 6" Deep	04.09.230.00	1-4
3	Temperature Probe (optional, Electronic Control only)	02.01.145.00	1-4
4	Drawer Front Assembly, Standard (includes items 5)	R04.16.515.00	1-4
	Drawer Front Assembly, Narrow (includes items 5)	R04.16.723.00	1-4
5	Handle, Drawer	R04.16.533.00	1-4
6	Drawer Roller—Drawer (2 per drawer)	R04.16.500.00	2-8
7	Drawer Roller—Core (4 per drawer)	04.16.638.00	4-16

Item	Description	Part No.	Qty.
8	Temperature Monitor, Drum	02.16.050.00	1-4
9	Knob, Temperature Control	05.30.047.00	1-4
10	Control Plate, Mechanical (standard)	07.01.179.00	1-4
11	Control Decal, Electronic (optional)	07.01.284.00	1-4
12	Complete Drawer Assembly, Standard (includes items 5 and 6)	R00.04.0003.00	1-4
	Complete Drawer Assembly, Narrow (includes items 5 and 6)	R00.04.0017.00	1-4
13	Splash Baffle (optional) *	04.06.204.00	1-4
14	Water/Spillage Pan (optional) *	04.09.231.00	1-4
15	Chip Guard, Standard (optional) *	04.16.732.00	1-4
	Chip Guard, Narrow (optional) *	04.16.829.00	1-4

* Not shown.

NOTE: Quantities shown as a range (example = "4-16") are dependent upon the number of drawers in a unit.

PARTS SPECIFIC TO MODELS HDW-1, -2, -3 AND -4 — US AND CANADA

Item	Description	120 V	208 V	240 V
16	ON/OFF Switch (Qty. 1–4)	R02.19.215.00	02.19.178.00	02.19.178.00
17	Temperature Control, Mechanical, w/Knob (Qty. 1–4, standard)	R02.16.046.00	R02.16.046.00	R02.16.046.00
18	Temperature Control, Electronic (Qty. 1–4, optional, includes item 3)	R02.01.222A.00	R02.01.295.00	R02.01.295.00
19	Heating Element, 450 W (Qty. 1–4)	02.05.052T.00	02.05.051T.00	02.05.050E.00
20	Power Cord	R02.18.030.00	02.18.036.00	02.18.036.00
21	Bracket, Leg/Caster (Qty. 4) †	04.16.547.00	04.16.547.00	04.16.547.00
22	Bolt, Bracket (Qty. 16)	05.04.201.00	05.04.201.00	05.04.201.00
23	Legs, 4" (Qty. 4, standard) †	05.30.007.00	05.30.007.00	05.30.007.00
24	Caster, 3" (Qty. 4, optional) †	04.17.130.00	04.17.130.00	04.17.130.00
25	Bracket, Leg, 6" (Qty. 4, optional [standard on HDW-4 models]) *	04.16.551.00	04.16.551.00	04.16.551.00
26	Legs, 6" (Qty. 4, optional [standard on HDW-4 models]) *	04.16.488.00	04.16.488.00	04.16.488.00
27	Caster, 2" (Qty. 2, optional) * †	04.16.635.00	04.16.635.00	04.16.635.00
28	Caster, 2", Locking (Qty. 2, optional) * †	04.16.645.00	04.16.645.00	04.16.645.00
29	Caster, 4" (Qty. 4, optional) *	04.26.004.00	04.26.004.00	04.26.004.00
30	Caster, 5" (Qty. 4, optional) *	04.26.343.00	04.26.343.00	04.26.343.00
	Wiring Diagram	HS1-1996	HS1-2000	HS1-2000

PARTS SPECIFIC TO MODELS HDW-1, -2, -3 AND -4 — INTERNATIONAL

Item	Description	100 V	220 V	240 V	220–230 V CE	230–240 V CE
16	ON/OFF Switch (Qty. 1–4)	R02.19.215.00	02.19.178.00	02.19.178.00	02.19.178.00	02.19.178.00
17	Temperature Control, Mechanical, w/Knob (Qty. 1–4, standard)	R02.16.046.00	R02.16.046.00	R02.16.046.00	R02.16.046.00	R02.16.046.00
18	Temperature Control, Electronic (Qty. 1–4, optional, includes item 3)	R02.01.222A.00	R02.01.295.00	R02.01.295.00	---	---
19	Heating Element, 450 W (Qty. 1–4)	02.05.054T.00	02.05.053E.00	02.05.050E.00	02.05.053E.00	02.05.050E.00
20	Power Cord	R02.18.030.00	02.18.038.00	02.18.068.00	02.18.038.00	02.18.068.00
21	Bracket, Leg/Caster (Qty. 4) †	04.16.547.00	04.16.547.00	04.16.547.00	04.16.547.00	04.16.547.00
22	Bolt, Bracket (Qty. 16)	05.04.201.00	05.04.201.00	05.04.201.00	05.04.201.00	05.04.201.00
23	Legs, 4" (Qty. 4, standard) †	05.30.007.00	05.30.007.00	05.30.007.00	05.30.007.00	05.30.007.00
24	Caster, 3" (Qty. 4, optional) †	04.17.130.00	04.17.130.00	04.17.130.00	04.17.130.00	04.17.130.00
25	Bracket, Leg, 6" (Qty. 4, optional [standard on HDW-4 models]) *	04.16.551.00	04.16.551.00	04.16.551.00	04.16.551.00	04.16.551.00
26	Legs, 6" (Qty. 4, optional [standard on HDW-4 models]) *	04.16.488.00	04.16.488.00	04.16.488.00	04.16.488.00	04.16.488.00
27	Caster, 2" (Qty. 2, optional) * †	04.16.635.00	04.16.635.00	04.16.635.00	04.16.635.00	04.16.635.00
28	Caster, 2", Locking (Qty. 2, optional) * †	04.16.645.00	04.16.645.00	04.16.645.00	04.16.645.00	04.16.645.00
29	Caster, 4" (Qty. 4, optional) *	04.26.004.00	04.26.004.00	04.26.004.00	04.26.004.00	04.26.004.00
30	Caster, 5" (Qty. 4, optional) *	04.26.343.00	04.26.343.00	04.26.343.00	04.26.343.00	04.26.343.00
	Wiring Diagram	HS1-1996	HS1-4518	HS1-4518	HS1-4518	HS1-4518

* Not shown.

† Not available on HDW-4 models.

NOTE: The last four digits in a ten digit numerical serial number are the manufacturing date code.

Example: Serial number 9625060951 has a date code of "0951" which indicates the following: 0951


 Week Fifty-One
Year 2009