







MOD : ASD/M-SS

Production code : SELFSERVICE (DIAM)

12/2024

DESPIECE - DIAGRAM


DESPIECE - DIAGRAM


SELF-SERVICE

REF.	Nº	REPUESTO	SPARE PARTS	
selfservice-001	1	Tornillo negro	Black screw	
selfservice-002	2	Plato giratorio	Turntable	
selfservice-003	3	Engranaje dentado 60	Tooth gearing 60	
selfservice-004	4	Casquillo negro cortado	Black cut spacer	
selfservice-005	5	Tornillo M5*8	Screw M5*8	
selfservice-006	6	Piñón 18 dientes inox	Inox gearing 18	
selfservice-007	7	Eje alimentador con chaveta	Feeder shaft with peg	
selfservice-008	8	Motor alimentador	Feeder motor	
selfservice-009	9	Condensador motor	Feeder capacitor	
selfservice-010	10	Casquillo negro	Black spacer	
selfservice-011	11	Tapa trasera superior	Top case back	
selfservice-012	12	Tapa trasera inferior	Under case back	
selfservice-013	13	Tornillo M5*10	Screw M5*10	
selfservice-014	14	Tapa motor alimentador	Feeder motor cover	
selfservice-015	15	Tornillo M5*10	Screw M5*10	
selfservice-016	16	Alimentador	Feeder	
selfservice-017	17	Rampa A	Ramp A	
selfservice-018	18	Rampa B	Ramp B	
selfservice-019	19	Visagra	Hinge	
selfservice-020	20	Tornillo M4*10	Screw M4*10	
selfservice-021	21	Cristal puerta	Door glass	
selfservice-022	22	Carcasa frontal	Front cover	
selfservice-023	23	Tornillo negro	Black screw	
selfservice-024	24	Cubo de inox	Inox cube	
selfservice-025	25	Bandeja posavasos	Tray for glasses	
selfservice-026	26	Rejilla posavasos	Grating for glasses	
selfservice-027	27	Filtro Arrastre	Removing Filter	
selfservice-027a		Pieza barredora	Sweeper piece	
selfservice-028	28	Tirador del filtro	Filter shooter	
selfservice-029	29	Embudo de filtración	Filter funnel	
selfservice-029x1		Embudo de filtración con colgador	Filter funnel with support	
selfservice-030	30	Pitón N4	Bottom M4	
selfservice-031	31	Quitacáscaras D	Peel extractor R	
selfservice-032	32	Quitacáscaras I	Peel extractor L	
selfservice-033	33	Soporte quitacáscaras D	Support extractor R	
selfservice-034	34	Soporte quitacáscaras I	Support extractor I	
selfservice-035	35	Bola	Squeezer Ball	
selfservice-036	36	Soporte cuchilla	Support cutting blade	
selfservice-037	37	Cuchilla	Cutting blade	
selfservice-038	38	Tornillo M5*10	Screw M5*10	
selfservice-039	39	Tornillo amarillo	Yellow screw	
selfservice-040	40	Hueco	Hollow item	
selfservice-041	41	Soporte carcasa	Support front cover	
selfservice-042	42	Eje exprimidor 4	Squeezer shaft 4	
selfservice-043	43	Eje exprimidor 3	Squeezer shaft 3	
selfservice-044	44	Eje exprimidor 1	Squeezer shaft 2	
selfservice-045	45	Eje exprimidor 2	Squeezer shaft 1	
selfservice-046	46	Chaveta 35'	Peg 35'	

SELF-SERVICE

REF.	Nº	REPUESTO	SPARE PARTS	
selfservice-047	47	Chaveta 55'	Peg 55'	
selfservice-047t		Tornillo Chaveta	Key Screw	
selfservice-048	48	Cojinete	Bearing of squeezer shaft	
selfservice-049	49	Goma tórica	O-ring seal	
selfservice-050	50	Casquillo amarillo	Yellow spacer	
selfservice-051	51	Chaveta 78'	Peg 78'	
selfservice-052	52	Interruptor de seguridad	Security switch	
selfservice-053	53	Interruptor alimentador	Feeder switch	
selfservice-054	54	Engranaje cónico 29	Conical gear 29	
selfservice-055	55	Engranaje cónico 14	Conical gear 14	
selfservice-056	56	Separador largo	Separator large	
selfservice-057	57	Separador corto	Separator short	
selfservice-058	58	Interruptor	Switch	
selfservice-059	59	Portafusible	Fuse holder	
selfservice-060	60	Fusible	Fuse	
selfservice-061	61	Motor	Motor	
selfservice-061x		Chapa sujuección motor	Motor fixing sheet	
selfservice-062	62	Cubierta cable de red	Network cable cover	
selfservice-063	63	Cable de red	Network cable	
selfservice-064	64	Condensador motor	Motor capacitor	
selfservice-065	65	Caja de conexiones	Junction box	
selfservice-066	66	Soporte caja d conexiones	Support junction box	
selfservice-067	67	Pata	Leg	
selfservice-068	68	Tornillo M5*10	Screw M5*10	
selfservice-069	69	Arandela M8	Washer M8	
selfservice-070	70	Tuerca M8	Nut M8	
selfservice-071	71	Tornillo M8*25	Screw M8*25	
selfservice-072	72	Engranaje dentado 45-4	Tooth gearing 45-4	
selfservice-073	73	Engranaje dentado 45-3	Tooth gearing 45-3	
selfservice-074	74	Engranaje dentado 60-1	Tooth gearing 60-1	
selfservice-075	75	Engranaje dentado 60-2	Tooth gearing 60-2	
selfservice-076	76	Cuerpo máquina	Machine's body	
selfservice-077	77	Grifo	Tap	
selfservice-078	78	Junta grifo x	Fix tap x	
selfservice-079	79	Fotocélula	Photocell	
selfservice-080	80	Relé	Relay	
selfservice-081	81	Base relé	Base relay	
selfservice-082	82	Mueble	Stand	
selfservice-083	83	Ruedas	Wheel	
selfservice-084	84	Rueda con freno	Wheel with brake	
selfservice-085	85	Soporte set salida inox	Support set ino output	
selfservice-086	86	Tirador mueble	Stand shooter	
selfservice-087	87	Cerradura mueble	Stand lock	
selfservice-088	88	Posavasos regulable	Adjustable tray for glasses	
selfservice-089	89	Filtro posavasos regulable	Adjustable grating for glasses	
selfservice-090	90	Retenedor del alimentador		



REPUESTOS EXPRIMIDORA ORANGE JUICER SPARE PARTS

SELF-SERVICE

REF.	Nº	REPUESTO	SPARE PARTS	
selfservice-100		Embalaje	Package	
selfservice-200		Pegatina	Sticker	
selfservice-000b		Botellero	Yellow spacer	
selfservice-000b1		Guias Botellero	Peg 78'	