# **Mod: DRF-BL**

**Production code: GRFFBL** 




# Glo-Ray<sup>®</sup> & Ultra-Glo<sup>™</sup> Portable Foodwarmer GR-B, GRFF & UGFF Series

# Installation & Operating Manual

I&W #07.05.181.00







This manual contains important safety information concerning the maintenance, use and operation of this product. Failure to follow the instructions contained in this manual may result in serious injury. If you're unable to understand the contents of this manual, please bring it to the attention of your supervisor. Do not operate this equipment unless you have read and understood the contents of this manual.

Este manual contiene importante información sobre seguridad concerniente al mantenimiento, uso y operación de este producto. Cualquier falla en el seguimiento de las instrucciones contenidas en este manual puede resultar en un serio daño. Si usted no puede entender el contenido de este manual por favor pregunte a su supervisor. No opere este equipo al menos que haya leído y comprendido el contenido de este manual.

#### **CONTENTS**

Important Owner Information	i	Installation	8
Introduction			
Important Safety Information	1	Location	8
Model Designations	2	Assembly	8
Model Descriptions	3	Operation	9
Specifications	4	Maintenance	10
Plug Configurations	4	Cleaning	10
Dimensions	4	Display Light Bulb Replacement	10
Glo-Ray Electrical Rating Chart	6	Accessories	11
Ultra-Glo Electrical Rating Chart		Hatco Limited Warranty	12
· ·		Authorized Parts Distributors	Back Cover

i

#### IMPORTANT OWNER INFORMATION

Record the model number, serial number (identification decal located on the unit), voltage and purchase date of your Portable Foodwarmer in the spaces below. Please have this information available when calling Hatco for service assistance.

Model No	 
Serial No	 
Voltage	 
Date of Purchase	 

#### INTRODUCTION

Hatco Glo-Ray® and Ultra-Glo<sup>™</sup> Portable Foodwarmers are designed to provide ideal heat patterns with precise temperature control to ensure food quality and safety. Pre-focused heat patterns prevent foods from overcooking in the middle or cooling off around the edges by concentrating higher temperatures to the outer edges of holding surfaces where heat loss is the greatest. Flexible heating options maximize food holding and minimize the risk of food-borne illnesses. Portable Foodwarmers safely maintain peak serving temperatures longer without continuing to cook the food.

Hatco Ultra-Glo ceramic pyramidal heat patterns create intense heat energy allowing for a greater working space between the warmer and the holding surface.

The Glo-Ray and Ultra-Glo Foodwarmers are available with or without shatter-resistant incandescent lights to illuminate the warming area. These bulbs have a special coating that guards against injury and food contamination in the event of breakage.

This manual provides the installation, safety and instructions operating for the Portable Foodwarmers. We recommend all installation. operating and safety instructions appearing in this manual be read prior to installation or operation of your Portable Foodwarmers. Safety instructions that appear in this manual after a warning symbol 1 and the words WARNING or CAUTION printed in bold face are very important. A WARNING means there is the possibility of serious personal injury or death to yourself or others. A CAUTION means there is the possibility of minor or moderate injury. NOTICE without the symbol signifies the possibility of equipment or property damage only.

Hatco Portable Foodwarmers are a product of extensive research and field testing. The materials used were selected for maximum durability, attractive appearance and optimum performance. Every unit is thoroughly inspected and tested prior to shipment.

#### IMPORTANT SAFETY INFORMATION

IMPORTANT! Read the following important safety information to avoid personal injury or death, and to avoid damage to the equipment or property.

#### **⚠ WARNINGS**

- ⚠ Plug unit into a properly grounded electrical outlet of the correct voltage, size and plug configuration. If the plug and receptacle do not match, contact a qualified electrician to determine the proper voltage and size and install the proper electrical outlet.
- For safe and proper operation, the unit must be located a minimum of 2" (51 mm) from combustible walls and materials. If safe distances are not maintained, discoloration or combustion could occur.
- To prevent any injury or damage to the unit do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.
- To prevent any injury or damage to the unit do not pull unit by power cord.
- To prevent any injury, discontinue use if power cord is frayed or worn and contact Authorized Service Agent to replace it.
- The unit is not waterproof. DO NOT submerge in water. Do not operate if it has been submerged in water.
- To avoid the risk of fire the base must be secured to top housing before turning on power.
- ⚠ If service is required on this unit, contact your Authorized Hatco Service Agent, or contact the Hatco Service Department at 800-558-0607 or 414-671-6350; fax 800-690-2966 or International fax 414-671-3976.
- This product has no "user" serviceable parts.

  To avoid damage to the unit or injury to personnel, use only Authorized Hatco Service Agents and Genuine Hatco Replacement Parts when service is required.

Genuine Hatco Replacement Parts are specified to operate safely in the environments in which they are used. Some aftermarket or generic replacement parts do not have the characteristics that will allow them to operate safely in Hatco equipment. It is essential to use Hatco Replacement Parts when repairing Hatco equipment. Failure to use Hatco Replacement Parts may subject operators of the equipment to hazardous electrical voltage, resulting in electrical shock or burn.

#### **⚠** CAUTIONS

- Some exterior surfaces on the unit will get hot. Use caution when touching these areas to avoid injury.
- Locate the unit at the proper counter height, in an area that is convenient for use. The location should be level to prevent the unit or its contents from accidentally falling, and strong enough to support the weight of the unit and food.
- ⚠ Unit is not weatherproof. For safe and proper operation locate the unit indoors where the ambient air temperature is constant and is a minimum of 70°F (21°C).
- ⚠ Standard and approved manufacturing oils will smoke up to 30 minutes during initial start-up. This is a temporary condition. To assure safe operation, operate unit without food product until smoke dissipates.

#### **NOTICE**

Use only non-abrasive cleaners. Abrasive cleaners could scratch the finish of your unit, marring its appearance and making it susceptible to dirt accumulation.

Damage to countertop material such as Corian® and similar products caused by heat generated from Hatco equipment is not covered under the Hatco warranty. Contact the manufacturer of the base material for application information.

#### **MODEL DESIGNATIONS**




Figure 1. Glo-Ray Model Designation




Figure 2. Ultra-Glo Model Designation

#### MODEL DESCRIPTIONS

#### **GR-B MODELS**

Hatco GR-B Models have a cast aluminum base with built-in heating element, built-in temperature control, On/Off rocker switch and standard pre-wired 6' (1829 mm) cord and plug.

## GRFF, GRFFL, GRFFB AND GRFFBL MODELS

Hatco GRFF, GRFFL, GRFFB and GRFFBL Models have aluminum housings equipped with a metal sheath infrared heating element, ON/OFF toggle switch, and a standard pre-wired 6' (1829 mm) cord and plug. The Portable Foodwarmer has optional base heat, incandescent lights, infinite control and display sign holder (sign not included). The unit is also available in six *Designer* colors.

GR-B: Glo-Ray Base Heat

**GRFF:** Glo-Ray French Fry Warmer with

Upper Heat

GRFFL: Glo-Ray French Fry Warmer with

Upper Heat and Incandescent Light Glo-Ray French Fry Warmer with

**GRFFB:** Glo-Ray French Fry Warmer Upper Heat and Base Heat

**GRFFBL:** Glo-Ray French Fry Warmer Upper Heat,

Base Heat and Incandescent Light

#### **ULTRA-GLO™ MODELS**

Hatco Ultra-Glo™ Portable Foodwarmers have aluminum housings equipped with a compact upper ceramic heating element, ON/OFF toggle switch, and a standard pre-wired 6' (1829 mm) cord and plug. The Portable Foodwarmer has optional base heat, incandescent lights, and is also available in five *Translucent Gloss* finishes.

**UGFF:** Ultra-Glo French Fry Warmer with

**Upper Heat** 

**UGFFL:** Ultra-Glo French Fry Warmer with

Upper Heat and Incandescent Light

**UGFFB:** Ultra-Glo French Fry Warmer with Upper

Heat and Base Heat

**UGFFBL:** Ultra-Glo French Fry Warmer with Upper

Heat, Base Heat and Incandescent Light

NOTE: Optional infinite control is not available on GR-B models, Ultra-Glo units or units with sign holders.

NOTE: GRFFB and GRFFBL models are equipped with a swing-away top to provide fast easy access to food product. (See Figure 6.)




Figure 3. GR-B Model




Figure 4. GRFFL Model




Figure 5. UGFFB Model




Figure 6. Swing-Away Top

#### **SPECIFICATIONS**

#### **PLUG CONFIGURATIONS**

Units are supplied from the factory with a 6' (1829 mm) electrical cord and plug installed. Plugs are supplied according to the applications. (See Figure 7.)

#### **⚠ WARNING**

Plug unit into a properly grounded electrical outlet of the correct voltage, size and plug configuration. If the plug and receptacle do not match, contact a qualified electrician to determine the proper voltage and size and install the proper electrical outlet.




Figure 7. Plug Configurations

#### **DIMENSIONS**

Models	Width (A)	Depth (B)	Height (C)	
GR-B	12-3/4" (324 mm)	22" (559 mm)	2-1/4" (57 mm)	)




Figure 8. Dimensions-GR-B Models

Models	Width (A)	Depth (B)	Height (C)	Interior Height (D)
GRFF	12-3/8"	24"	15-7/8"	9-1/8"
	(314 mm)	(610 mm)	(403 mm)	(232 mm)
GRFFL	12-3/8"	24"	15-7/8"	9-1/8"
	(314 mm)	(610 mm)	(403 mm)	(232 mm)





Figure 9. Dimensions-GRFF & GRFFL Models

Models	Width (A)	Depth (B)	Height† (C)	Interior Height* (D)
GRFFB	12-3/4"	24"	16"-20"	14"
	(324 mm)	(610 mm)	(406-508 mm)	(356 mm)
GRFFBL	12-3/4"	24"	16"-20"	14"
	(324 mm)	(610 mm)	(406-508 mm)	(356 mm)

†Add 3" (76 mm) to height of unit when using display sign holder.






Figure 10. Dimensions-GRFFB & GRFFBL Models

Models	Width (A)	Top Depth (B)	Bottom Depth (C)	Height (D)	Interior Height (E)
UGFF	12-3/8"	18"	22-1/4"	18-7/8"	12"
	(314 mm)	(457 mm)	(565 mm)	(479 mm)	(305 mm)
UGFFL	12-3/8"	18"	22-1/4"	18-7/8"	12"
	(314 mm)	(457 mm)	(565 mm)	(479 mm)	(305 mm)




Figure 11. Dimensions-UGFF & UGFFL Models

Models	Width (A)	Top Depth (B)	Bottom Depth (C)	Height (D)	Interior Height* (E)
UGFFB	12-3/4"	18"	22-1/2"	22"	18"
	(324 mm)	(457 mm)	(572 mm)	(559 mm)	(457 mm)
UGFFBL	12-3/4"	18"	22-1/2"	22"	18"
	(324 mm)	(457 mm)	(572 mm)	(559 mm)	(457 mm)

<sup>\* 18&</sup>quot; (457 mm) clearance is standard. Optional clearances, not available for retro-fit are, 14-1/2" (368 mm), 15" (381 mm), 16-3/4" (425 mm) and 19" (483 mm).




Figure 12. Dimensions-UGFFB & UGFFBL Models

#### **SPECIFICATIONS**

**ELECTRICAL RATING CHART-GLO-RAY PORTABLE FOODWARMER MODELS** 

Model	Voltage	Watts	Amps	Shipping Weights
GR-B	120	250	2.1	16 lbs. (7 kg)
	220	250	1.1	16 lbs. (7 kg)
	240	250	1.0	16 lbs. (7 kg)
	220-230 (CE)	210-230	1.0	16 lbs. (7 kg)
	230-240 (CE)	230-250	1.0	16 lbs. (7 kg)
GRFF	100	500	5.0	16 lbs. (7 kg)
	120	500	4.2	16 lbs. (7 kg)
	220	500	2.3	16 lbs. (7 kg)
	240	500	2.1	16 lbs. (7 kg)
	220-230 (CE)	500-546	2.3-2.4	16 lbs. (7 kg)
	230-240 (CE)	459-500	2.0-2.1	16 lbs. (7 kg)
GRFFL	100	584	5.8	18 lbs. (8 kg)
	120	620	5.2	18 lbs. (8 kg)
	220	600	2.7	18 lbs. (8 kg)
	240	620	2.6	18 lbs. (8 kg)
	220-230 (CE)	600-656	2.7-2.9	18 lbs. (8 kg)
	230-240 (CE)	569-620	2.5-2.6	18 lbs. (8 kg)
GRFFB	100	750	7.5	26 lbs. (12 kg)
	120	750	6.3	26 lbs. (12 kg)
	220	710	3.2	26 lbs. (12 kg)
	240	750	3.1	26 lbs. (12 kg)
	220-230 (CE)	710-777	3.2-3.4	26 lbs. (12 kg)
	230-240 (CE)	689-750	3.0-3.1	26 lbs. (12 kg)
GRFFBL	100	833	8.3	31 lbs. (14 kg)
	120	870	7.3	31 lbs. (14 kg)
	220	810	3.7	31 lbs. (14 kg)
	240	870	3.6	31 lbs. (14 kg)
	220-230 (CE)	810-867	3.7-3.8	31 lbs. (14 kg)
	230-240 (CE)	799-870	3.5-3.6	31 lbs. (14 kg)

The electrical information in the shaded area pertains to **Export Models** only.

#### **SPECIFICATIONS**

#### ELECTRICAL RATING CHART-ULTRA-GLO CERAMIC PORTABLE FOODWARMER MODELS

Model	Voltage	Watts	Amps	Shipping Weights
UGFF	100	625	6.3	15 lbs. (7 kg)
	120	750	6.3	15 lbs. (7 kg)
	220	630	2.8	15 lbs. (7 kg)
	240	750	3.1	15 lbs. (7 kg)
	220-230 (CE)	630-689	2.9-3.0	15 lbs. (7 kg)
	230-240 (CE)	689-750	3.0-3.1	15 lbs. (7 kg)
UGFFL	100	708	7.1	19 lbs. (9 kg)
	120	870	7.3	19 lbs. (9 kg)
	220	730	3.3	19 lbs. (9 kg)
	240	870	3.6	19 lbs. (9 kg)
	220-230 (CE)	730-799	3.3-3.5	19 lbs. (9 kg)
	230-240 (CE)	799-870	3.5-3.6	19 lbs. (9 kg)
UGFFB	100	875	8.8	26 lbs. (12 kg)
	120	1000	8.3	26 lbs. (12 kg)
	220	840	3.8	26 lbs. (12 kg)
	240	1000	4.2	26 lbs. (12 kg)
	220-230 (CE)	840-919	3.8-4.0	26 lbs. (12 kg)
	230-240 (CE)	919-1000	4.0-4.2	26 lbs. (12 kg)
UGFFBL	100	959	9.6	31 lbs. (14 kg)
	120	1120	9.3	31 lbs. (14 kg)
	220	940	4.3	31 lbs. (14 kg)
	240	1120	4.7	31 lbs. (14 kg)
	220-230 (CE)	940-1029	4.3-4.5	31 lbs. (14 kg)
	230-240 (CE)	1029-1120	4.5-4.7	31 lbs. (14 kg)

The electrical information in the shaded area pertains to **Export Models** only.

#### **INSTALLATION**

#### UNPACKING

- 1. Remove the unit from the carton and remove all packing materials.
- 2. Remove information packet. To prevent delay in obtaining warranty coverage, fill out and mail in warranty card.

NOTE: If unit is equipped with optional equipment, see ACCESSORIES section at back of this manual.

#### **ELECTRICAL WIRING HOOK-UP**

Refer to the *ELECTRICAL RATING CHARTS* for specific information.

#### **Power Cord and Plug Models**

Install an approved grounded receptacle to match the plug and cord supplied with the unit.

#### **LOCATION**

#### **A** CAUTION

Locate the unit at the proper counter height, in an area that is convenient for use. The location should be level to prevent the unit or its contents from accidentally falling, and strong enough to support the weight of the unit and food.

#### **⚠ WARNING**

For safe and proper operation, the unit must be located a minimum of 2" (51 mm) from combustible walls and materials. If safe distances are not maintained, discoloration or combustion could occur.

#### **∴** WARNING

To prevent any injury or damage to the unit do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

#### **⚠** CAUTION

Unit is not weatherproof. For safe and proper operation locate the unit <u>indoors</u> where the ambient air temperature is constant and is a minimum of 70°F (21°C).

#### **ASSEMBLY**

#### **GR-B Model**

Model GR-B is preassembled. Follow unpacking instructions before operating unit.

GRFF, GRFFL, UGFF & UGFFL, Models

#### **⚠** WARNING

To avoid the risk of fire the base must be secured to top housing before turning on power.




Figure 13. Assembly of Top Housing and Leg Bracket




Figure 14. Assembly of Top Housing with Leg Bracket to Base Unit

NOTE: A Phillips Screwdriver is required for this assembly.

- Remove top housing, leg brackets, and base unit from carton and set parts on a non-scratch surface.
- 2. Remove all packaging materials from unit.
- 3. Position the top housing, element side up, on a non-scratch surface.
- 4. Using the four screws provided attach both leg brackets to the top housing. (See Figure 13.)
- 5. Secure top assembly to base unit using lock washers and wing nuts provided. (See Figure 14.)
- 6. Place unit in desired location.

#### GRFFB, GRFFBL, UGFFB & UGFFBL Models

- 1. Remove Portable Foodwarmer from carton and set pre-assembled unit upright.
- 2. Remove all packaging materials from unit.
- 3. Insert chrome pan rail open end first. (See Figure 15.)
- 4. Push adjacent end down firmly. For proper fitting, chrome pan rail will rest on top of base unit.
- 5. Place unit in desired location.

NOTE: When transporting Portable Foodwarmers, always allow unit to cool down before moving it. Be sure to support top housing and base unit together.




Figure 15. Assembly of Chrome Pan Rail

#### **OPERATION**

#### **⚠ WARNING**

To prevent any injury or damage to the unit do not pull unit by power cord.

#### **⚠ WARNING**

To prevent any injury, discontinue use if power cord is frayed or worn and contact Authorized Service Agent to replace it.

#### **⚠** CAUTION

Some exterior surfaces on the unit will get hot. Use caution when touching these areas to avoid injury.

#### **∴** WARNING

The unit is not waterproof. DO NOT submerge in water. Do not operate if it has been submerged in water.

#### **⚠** CAUTION

Standard and approved manufacturing oils will smoke up to 30 minutes during initial start-up. This is a temporary condition. To assure safe operation, operate unit without food product until smoke dissipates.

#### **NOTICE**

Damage to countertop material such as Corian® and similar products caused by heat generated from Hatco equipment is not covered under the Hatco warranty. Contact the manufacturer of the base material for application information.




Figure 16. Controls

#### **HEATING ELEMENT**

Heating element is controlled by an ON/OFF switch or an optional infinite control. To turn the element on, either flip the switch in the ON position or turn the infinite control to the desired setting.

Allow 15-20 minutes to reach operating temperature.

NOTE: Model GR-B controlled by an On/Off rocker switch.

NOTE: Optional infinite control is not available on the GR-B Model, Ultra-Glo units, or units with sign holders.

#### **LIGHTS**

On models equipped with lights, flip the toggle switch to the ON position or turn optional infinite control to energize the lights.

#### **MAINTENANCE**

#### **CLEANING**

Hatco Glo-Ray® and Ultra-Glo™ Portable Foodwarmer units are designed for maximum durability and performance, with minimum maintenance.

#### **⚠ WARNING**

To avoid any injury, turn the power switch OFF unplug the unit from the power source and allow to cool completely before performing any maintenance and cleaning.

To preserve the finish of the Glo-Ray and Ultra-Glo Portable Foodwarmer, it is recommended that the surfaces be wiped daily with a clean, soft, damp cloth. Stubborn stains maybe be removed with a good stainless steel cleaner or a non-abrasive cleaner. Hard to reach areas should be cleaned with a small brush and mild soap.

#### **NOTICE**

Use only non-abrasive cleaners. Abrasive cleaners could scratch the finish of your unit marring its appearance and making it susceptible to soil accumulation.

#### **DISPLAY LIGHT BULB REPLACEMENT**

The display light is an incandescent bulb which illuminates the warming area. This bulb has a special coating to guard against injury and food contamination in the event of breakage.

To replace a bulb, disconnect the power supply and wait until the unit has cooled. Display lamps have a threaded base. Unscrew the bulb from the unit and replace it with a new specially coated incandescent bulb. Hatco shatter-resistant bulbs meet NSF standards for food holding and display areas.

NOTE: Hatco shatter-resistant light bulbs meet NSF standards for food holding and display areas. For 120 Volt applications, use Hatco part number 02.30.043.00. For 220, 240, 220-230 and 230-240 Volt applications, use Hatco part number 02.30.058.00.

#### **⚠ WARNING**

Only light bulbs which meet or exceed NSF standards, specially designed for food holding areas may be used. Breakage of light bulbs not specially coated could result in personal injury and/or food contamination.

#### **⚠ WARNING**

If service is required on this unit, contact your Authorized Hatco Service Agent, or contact the Hatco Service Department at 800-558-0607 or 414-671-6350; fax 800-690-2966 or International fax 414-671-3976.

#### **⚠ WARNING**

This product has no "user" serviceable parts. To avoid damage to the unit or injury to personnel, use only Authorized Hatco Service Agents and Genuine Hatco Replacement Parts when service is required.

#### **⚠ WARNING**

Genuine Hatco Replacement Parts are specified to operate safely in the environments in which they are used. Some aftermarket or generic replacement parts do not have the characteristics that will allow them to operate safely in Hatco equipment. It is essential to use Hatco Replacement Parts when repairing Hatco equipment. Failure to use Hatco Replacement Parts may subject operators of the equipment to hazardous electrical voltage, resulting in electrical shock or burn.

#### SIGN HOLDER

The optional 9" (229 mm) width x 5-1/2" (140 mm) height display sign holder is also available for the Portable Foodwarmer used in a self serve area. (Sign not included.)

NOTE: Display sign holder is only available on the GRFFL model with toggle switch.

To install the optional sign holder follow these instructions:

- 1. Remove two outer screws from front of unit (See Figure 17).
- 2. Install sign holder using original screws.
- 3. Install sign (not provided) and acrylic panel.

# FIVE PLEAT HARDCOATED FRY BOX RIBBON

A five (5) pleated hardcoated box tray can be added to hold french fry boxes. (See Figure 18.)

#### EIGHT PLEAT HARDCOATED FRY BAG RIBBON

An eight (8) pleated hardcoated fry bag tray can be added to hold french fry bags. (See Figure 19.)

#### INCANDESCENT LIGHT

The Portable Foodwarmers with aluminum housings may be equipped with incandescent display lights to illuminate the warming area.

Shatter-resistant bulbs guard against injury and food contamination in the event of breakage. The display lighting meets NSF standards for food holding and display areas.

NOTE: Display lights cannot be retrofitted to units.

#### INFINITE CONTROL

An optional infinite control is available for a more precise temperature control.

NOTE: Optional infinite control is not available on the GR-B Model, Ultra-Glo units, or units with sign holders.




Figure 17. Installing Optional Sign Holder - GRFFL Model with Toggle Switch




Figure 18. Five Pleat Hardcoated Fry Box Ribbon




Figure 19. Eight Pleat Hardcoated Fry Bag Ribbon

#### FOOD HOLDING PANS

Third, half and full size stainless steel food holding pans available.

#### WIRE TRIVETS

Quarter, half and full size wire trivets in stainless steel or plated finish.

#### HATCO LIMITED WARRANTY

#### 1. PRODUCT WARRANTY

Hatco warrants the products that it manufactures (the "Products") to be free from defects in materials and workmanship, under normal use and service, for a period of one (1) year from the date of purchase when installed and maintained in accordance with Hatco's written instructions or 18 months from the date of shipment from Hatco. Buyer must establish the product's purchase date by returning Hatco's Warranty Registration Card or by other means satisfactory to Hatco in its sole discretion.

Hatco warrants the following Product components to be free from defects in materials and workmanship from the date of purchase (subject to the foregoing conditions) for the period(s) of time and on the conditions listed below:

a) One (1) Year Parts and Labor PLUS One(1) Additional Year Parts-Only Warranty:

Toaster Elements (metal sheathed)
Drawer Warmer Elements (metal sheathed)
Drawer Warmer Drawer Rollers and Slides
Food Warmer Elements (metal sheathed)
Display Warmer Elements (metal sheathed
air heating)

Holding Cabinet Elements (metal sheathed air heating)

- b) One (1) Year Parts and Labor PLUS Four (4) Years Parts-Only Warranty on pro-rated terms that Hatco will explain at Buyer's request:
   3CS and FR Tanks
- c) One (1) Year Parts and Labor PLUS Nine
   (9) Years Parts-Only Warranty on:
   Electric Booster Heater Tanks

Gas Booster Heater Tanks

THE FOREGOING **WARRANTIES** ARE EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT INFRINGEMENT. Without limiting the generality of the foregoing, SUCH WARRANTIES DO NOT COVER: Coated incandescent light bulbs, fluorescent lights, lamp warmer heat bulbs, glass components, Product failure in booster tank, fin tube heat exchanger, or heating equipment, other water caused by liming, sediment buildup, chemical attack or freezing, Product misuse, tampering misapplication, improper installation or application of improper voltage.

### 2. LIMITATION OF REMEDIES AND DAMAGES

Hatco's liability and Buyer's exclusive remedy hereunder will be limited solely, at Hatco's option, to repair or replacement by a Hatco-authorized service agency (other than where Buyer is located outside of the United States, Canada, United Kingdom or Australia in which case Hatco's liability and Buyer's exclusive remedy hereunder will be limited solely to replacement of part under warranty) with respect to any claim made within the applicable warranty period referred to above. Hatco reserves the right to accept or reject any such claim in whole or in part. Hatco will not accept the return of any Product without prior written approval from Hatco, and all such approved returns shall be made at Buyer's sole expense. HATCO WILL NOT BE LIABLE, UNDER ANY CIRCUMSTANCES. **FOR** CONSEQUENTIAL OR INCIDENTAL DAMAGES, INCLUDING BUT NOT LIMITED TO LABOR COSTS OR LOST **PROFITS** RESULTING FROM THE USE OF OR INABILITY TO USE THE PRODUCTS OR FROM THE PRODUCTS BEING INCORPORATED IN OR BECOMING A COMPONENT OF ANY OTHER PRODUCT OR GOODS.

#### HATCO AUTHORIZED PARTS DISTRIBUTORS

**IOWA** 

**NEW YORK** 

**TEXAS** 

Jones McLeod Appl. Svc. Acme American Repairs, Inc. GCS Service Electric Motor Service Co. Fort Worth 817-831-0381 Birmingham 205-251-0159 Davenport 319-323-1823 Brooklyn 718-456-6544 Armstrong Repair Service **ARIZONA** Goodwin Tucker Group Alpro Service Co. 713-666-7100 515-262-9308 718-386-2515 Houston Des Moines Brooklyn Auth. Comm. Food Equip. Commercial Kitchen Repair Co. Phoenix 602-234-2443 **KENTUCKY** Appliance Installation Buffalo 716-884-7425 San Antonio 210-735-2811 Byassee Equipment Co. Certified Service Center 602-252-0402 859-254-8854 Northern Parts Dist. UTAH Phoenix Lexington Plattsburgh 518-563-3200 La Monica's Rest. Equip. Service Certified Service Center **CALIFORNIA** 502-964-7007 J.B. Brady, Inc. Murray 801-263-3221 Louisville Industrial Electric 315-422-9271 Syracuse **LOUISIANA VIRGINIA** Commercial Parts & Service, Inc. **NORTH CAROLINA Huntington Beach** 714-379-7100 Chandlers Parts & Service Daubers Chapman Appl. Service Baton Rouge 225-272-6620 Authorized Appliance Norfolk 757-855-4097 619-298-7106 Charlotte 704-377-4501 San Diego Daubers MARYLAND Springfield 703-866-3600 P & D Appliance <u>OHIO</u> Electric Motor Service Commercial Parts & Service, Inc. WASHINGTON 410-467-8080 Baltimore Akron/Canton Comm. Svc. Inc. 650-635-1900 S. San Francisco 330-753-6635 Akron Restaurant Appl. Service GCS Service **COLORADO** 206-524-8200 Certified Service Center Seattle Silver Spring 301-585-7550 Hawkins Commercial Appliance 513-772-6600 Cincinnati WISCONSIN MASSACHUSETTS 303-781-5548 Englewood Commercial Parts and Service A.S.C., Inc. Ace Service Co., Inc 614-221-0057 **FLORIDA** Columbus 608-246-3160 Madison Needham 781-449-4220 Electrical Appl. Repair Service Whaley Foodservice Repair A.S.C., Inc. **MICHIGAN** 216-459-8700 Jacksonville 904-725-7800 Independence Milwaukee 414-543-6460 Commercial Kitchen Service E. A. Wichman Co. Nass Service Co., Inc. Bay City 517-893-4561 419-385-9121 Orlando 407-425-2681 Toledo Bildons Appliance Service **CANADA** B.G.S.I. **OKLAHOMA** 248-478-3320 Detroit Pompano Beach 954-971-0456 Hagar Rest. Service, Inc. Midwest Food Equip. Service Comm. Appliance Service Oklahoma City 405-235-2184 616-261-2000 Grandville Tampa 813-663-0313 **ALBERTA** Krueger, Inc. **MINNESOTA** Key Food Equipment Service **GEORGIA** Oklahoma City 405-528-8883 GCS Service 780-438-1690 Edmonton TWC Services OREGON Minneapolis 612-546-4221 Smyrna 770-438-9797 **BRITISH COLUMBIA** Ron's Service, Inc. 503-624-0890 Key Food Equipment Service Heritage Service Group Portland General Parts 866-388-9837 604-433-4484 Norcross Vancouver **PENNSYLVANIA** Kansas City 816-421-5400 **MANITOBA** Southeastern Rest. Svc. Elmer Schultz Services Norcross 770-446-6177 Commercial Kitchen Services 215-627-5401 Air Rite, Inc. Philadelphia St. Louis 314-890-0700 Winnepeg 204-895-2300 **HAWAII** FAST Comm. Appl. Service Kaemmerlen Parts & Service Philadelphia 215-288-4800 **NEW BRUNSWICK** Burney's Comm. Service, Inc. 314-535-2222 St. Louis 808-848-1466 Honolulu Appliance Installation & Service EMR Services, Ltd. **NEBRASKA** 412-809-0244 Moncton 506-855-4228 Food Equip Parts & Service Pittsburgh Anderson Flectric Honolulu 808-847-4871 **ONTARIO** K & D Service Co. Omaha 402-341-1414 717-236-9039 Harrisburg ILLINOIS R.G. Henderson Ltd. **NEVADA** 416-422-5580 Electric Repair Co. Toronto Parts Town 610-376-5444 708-865-7278 Burney's Commercial Reading Lombard Choquette CKS 702-736-0006 Las Vegas **RHODE ISLAND** Ottawa 613-739-8458 Eichenauer Elec. Service Hi. Tech Commercial Service 217-429-4229 Decatur Marshall Electric Co. **QUÉBEC** N. Las Vegas 702-649-4616 401-331-1163 Midwest Elec. Appl. Service Providence Choquette CKS **Elmhurst** 630-279-8000 **NEW JERSEY SOUTH CAROLINA** 514-722-2000 Montreal Jay Hill Repair Cone's Repair Service Choquette CKS Whaley Foodservice Repair 973-575-9145 Fairfield Moline 309-797-5323 418-681-3944 803-791-4420 Québec City W. Columbia Service Plus **INDIANA TENNESSEE** 973-691-6300 Flanders GCS Service Camp Electric Indianapolis 317-545-9655 Memphis 901-527-7543

**ALABAMA**