


06/2022



Mod: SL80-NP

Production code: 9998PELD80HP-DDXXB



WIRES IN ALL APPLIANCES —
WIRES IN SOMEAPPLIANCES - - -

F: RADIO INTERFERENCE FILTER
CO: COMPRESSOR
M: MOTOR
SV: SWITCHING VALVE
DS: DOOR SWITCH
DP: DRAIN PUMP
FA: FAN
LB: LIGHT BULB
COMM: COMMUNICATION FOR MOTOR
NTC: THERMISTOR
FS: FLOAT SWITCH
UI: USER INTERFACE BOARD
EADBS: EXTRNAL AUTODOSING BOOKING SYSTEM



SERVICE MENU:
TURN OFF POWER (S1)
HOLD S6 AND S7 THEN TURN POWER ON (S1)
HOLD S6 AND S7 FOR ANOTHER 5 SEC WHEN POWER IS ON

ROTATE DIAL J1 TO SCROLL THROUGH SERVICE MENU
PRESS S3 TO ACCESS MENU STEP
FOR LEAVING EACH STEP TO BACK MENU, PRESS S7
PRESSING S3 STORES ALL SELECTIONS MADE AND EXITS SERVICE MENU

