

04/2019

Mod: RVG/112-CM

Production code: 8000011G



USER'S MANUAL

GAS VERTICAL OVENS

**RVG/2-CM
RVG/3-CM
RVG/4-CM
RVG/6-CM
RVG/112-CM
RVG/8-CM
RVG/152-CM**

INDEX

Chapter 1....	General description
Chapter 2....	Apparatus' use
Chapter 3.....	Loading and cleaning the oven
Chapter 4....	Technical instructions for installation and adjustment
Chapter 5....	Spare parts assembly
Appendix A..	List of spare parts and electric diagrams p. 66
Appendix B..	Gas categories and pressures p.67

CHAPTER 1

GENERAL DESCRIPTION

INDICATIONS

This apparatus should be installed in compliance with legislation in force and should be used in well ventilated areas only. Read the instructions prior to installation and use. For correct combustion the place where the grill is installed must have at least a minimum ventilation 10m³ / h of air per kW of heat input in operation. Consult instructions before installation and use.

When installing the oven, you should follow the instructions and requirements of the gas supplier and, in any case, contract an authorised technician to install it.

The apparatuses described below are for collective use and should only be handled by suitably qualified personnel. This apparatus is model A: without fan.

DESCRIPTION OF THE APPARATUS

All vertical models are made in stainless steel except the components that are used to handle

Basically, the following elements are present in the various model comprising the range of vertical ovens

- a) Structure
- b) Transmission
- c) Electric controls panel
- d) Gas equipment
- e) Doors
- f) Accessories

STRUCTURE

The dimensions of the part meant to support the various elements of the oven will depend on the number of spits in the oven and on whether or not it is to be assembled on a base.

TRANSMISSION

The transmission of the apparatus is by chain which will make all the spits turn synchronically. Transmission is moved by a motor reducer whose turnover speed is 4.5 r.p.m.

ELECTRIC EQUIPMENT

This comprises the motor described in the previous section and a luminous control switch situated at the bottom left of the apparatus.

WARNING: The oven is connected to the mains at 230V for the gas models

GAS EQUIPMENT

This consists of as many infrared burners, with their corresponding safety valves and thermocouples situated one above the other and separated by an inter-burner sheet, as there are spits in the specific oven model.

It is all fed through a battery with a feed input of 3/4" gas for the apparatuses running on Natural Gas or 1/2" gas for those running on Butane/Propane.

DOORS

The doors consist of two panes of tempered glass with insulated handles. The glass panels are assembled on the front of the oven. Their purpose is to protect you from the heat while the oven is in operation and to protect the food from external agents.

WARNING: Try not to hit the glass as they could break either at that moment or else later without any apparent reason for their doing so.

Do not leave any burner on when the doors are closed unless there is food roasting on the spit in question, the glass can explode.

Keep the glass clean and check that it is dry before each operation.

ACCESSORIES

The oven is equipped with a series of accessories such as the spits, skewers, hook for removing the spits and tray.

a) Spits

Their purpose is to fix, through the skewers, the food to be roasted. Their cross-section is square so that they will rotate when placed in the drag axles. The spits are equipped with insulated handles to avoid burns. The number of spits depends on the oven model. Maximum 9kg per spit. Always Respect Maximum Spit Load. Non Respect can damage the motor.

b) Skewers

Your rotisserie is provided with 2 simple skewers with screw (end) and 4 double skewers (center). These skewers are necessary for 6 chickens.

c) Tray

The tray is situated inside the roasting chamber beneath the spits with the purpose of collecting all the juices from the roast. It is not necessary to put water on it.

WARNING: IT IS COMPULSORY WEARING GLOVES WHEN HANDLING THE SPIT OR THE ROASTER TRAY

CHAPTER 2

APPARATUS' USE

LIGHTING THE BURNERS

The oven should be connected to a mains plug with an earth and neutral connection. The type and pressure of the gas should correspond to what is indicated on the characteristics plate.

Once this has been checked, proceed as follows:

- Open the general gas tap
- Open the doors.
- Press in the control of the required burner and make a quarter turn anti-clockwise until the "maximum" position is reached (**Fig. 3**).
- Without releasing, approach the burner with an open flame until it lights up. Wait 10 to 15 seconds before releasing; the burner should remain alight.
- To set the control to "minimum", turn the control anticlockwise from the "maximum" position until reaching the "minimum" one, without pressing (**Fig. 3**).
- To switch the burner off, turn the control from any position in a clockwise direction to the "off" indicator.
- Do not leave any burner on when the doors are closed unless there is food roasting on the spit in question, the glass can explode.




Fig. 3

ORDER FOR LIGHTING

Always start at the top of the oven downwards until you reach the bottom layer.

WARNING: *You should never leave a burner on for roasting when the one below it is off. Close the regulators and taps when the oven is not in use.*

ROTATION OF THE SPITS

When you press the switch at the bottom left of your oven, this will light up and the spits will start to turn. Upon pressing it again, the pilot lamp will go out and the spits will stop turning

CHAPTER 3

LOADING AND CLEANING THE OVEN

LOADING THE OVEN

- a) Put the simple skewer (1) in the spit (3) until it reaches the safety limit of the spit. Then fix it with the screw (2). (See fig. 5).
- b) Then place a chicken on the spit and hold it in place with the skewer already in position. Put the double skewer (4) on the spit and in a chicken. Repeat this operation until the spit is fully loaded and finally put a simple skewer in place and fix it with its screw.




Fig. 5

CLEANING

You can use any product on the market for cleaning your oven. Take care not to spill any cleaning liquid on the perforated surface of the burner. Do not use abrasive products as they could damage the surfaces of stainless steel.

The quality of your roasts depends on the cleanliness of your oven.

CLEANING THE INTER-BURNER SHEET

This sheet, situated between the burners, can be removed to facilitate cleaning. To do this, proceed as follows: **(fig. 6).**

- a) Pull the bottom of the sheet towards you until it is horizontal.
- b) Lift it until you notice that the sheet has reached a limit.
- c) Then pull it outwards and the sheet will have been extracted from the oven.

To replace it, proceed as follows:

- a) Enter the sheet horizontally so that its side grooves coincide with the pivots on each side.
- b) Let the sheet swing downwards.




Fig. 6

NOTE: It is advisable to have your oven inspected regularly by an authorised technician. By doing so, you will be sure that your oven is always in perfect working condition.

CHANGE OF GAS TYPE

It is advisable to call a qualified installer to install the device, and if necessary, to adapt it to use another type of gas.

CHAPTER 4

THECNICAL INSTRUCTIONS FOR INSTALLATION AND ADJUSTMENT

The appliance must be placed on a flat, stable surface. This device must be installed in accordance with the regulations in force, and should be used only in well-ventilated areas. For correct combustion the place where the grill is installed must have at least a minimum ventilation $10\text{m}^3 / \text{h}$ of air per kW of heat input in operation

SPACE

To be installed correctly, the oven requires a space at least equal to its own dimensions plus the necessary distance from a wall or any other apparatus as described in **Fig. 2**. The minimum distance to be observed from any point of the device to any combustible material must be 2 meters. However, the installation of a smoke extractor bell is recommended to prevent any damage to the ceiling of the premises in which it is installed as well as any deterioration caused by the heat, smoke and fats expelled during operation.

Roasters up to 4 broches must be installed above one of our in order to have the best ventilation. Otherwise they must be installed at least at 10cm from the floor.

USE AND INSTALLATION OF STANDS

Roaster must be placed on the support so that the brake wheels remain on the front of the grill. Wheels must be always braked.

In case of placing a posteriori the spit on the support, to set the grill this has some omega-shaped attachments to the grill cannot be moved on the support itself.

WARNING: Check the measures indicated in Chapter 5, section "Technical Data", prior to setting up or installing the oven"





FIG. 2.

WARNING:

Before operating the oven, make sure that the voltage as well as the pressure and type of gas coincide with the indications on the characteristics plate situated bottom left on the front of the apparatus.

Do not place any object on top of the oven or along its sides that could obstruct the ventilation grilles.




WARNING: Do not forget to adjust the burner minimum once you have changed the type of gas and change the label reading “Apparatus prepared for:... ” situated above the oven's gas inlet

MINIMUM BURNER ADJUSTMENT

- Remove the control of the valve of the burner you wish to adjust.
- Put a screwdriver through the hole in the control panel and loosen the screw (1) **Fig. 8** in a clockwise direction to reduce the minimum or anticlockwise to increase the minimum.
- Replace the control once the minimum has been adjusted


Fig 8



TAUTENING THE CHAIN

- Remove totally the screws fastening the transmission cover and remove it
- Loosen slightly screw (1) fig. 9 and move the tautener to the left. Fasten the tautener again by tightening the screw (1) once the chain is properly tautened.

Fig. 9



CHAPTER 5


ASSEMBLY OF SPARE PARTS

WARNING: *These operations can only be done by an authorised technician*

CHANGING THE MOTOR REDUCER

- remove the Disconnect the oven from the mains. Remove the cover of the transmission on the left side of the oven by loosening the screws fastening it.
- Loosen the screws (4) Fig. 10 to remove the chain that joins the pinion (3) and the axle of the first spit.
- Once the chain has been removed, totally remove the screws (4) to take out the motor support (5) along with the motor reducer.
- Loosen the screw fastening the pinion (3) to the axle of the motor reducer to remove it from the axle. Totally screws (2) to dismount the motor reducer from the support.
- Change the motor reducer and proceed in reverse order to what is explained above to assemble it.

WARNING *When correctly tautened the motor chain should have a flexion in the centre of about 1 cm. An excessively taut chain produces unnecessary work stress on the motor reducer.*



CHANGING A VALVE

- Disconnect the oven from the mains and close the gas supply. ***Make sure the gas supply is closed before you continue with this operation.***
- Remove all the valve controls (on the right of the oven) by pulling them outwards.
- Remove totally the screws fastening the controls panel and remove it
- Loosen the tube (12) (See Fig. 7) by loosening the nuts (11) of the valve you wish to change. Then dismount the thermocouple of the valve by loosening the nut (15).
- Totally loosen the screws (10) which, together with the bracket (9), fasten the valve to the battery.
- Proceed in reverse order to what is explained above to assemble the new valve. Do not forget to replace the washer of the joint (1) with a new one.
- Make sure there are no gas leaks. Then adjust the minimum of the burner and finally replace the controls panel.

CHANGING A THERMOCUPLE

- a) Disconnect the oven from the mains and close the gas supply. **Make sure that the gas supply is closed before you continue with this operation.**
- f) Remove all the valve controls (on the right of the oven) by pulling them outwards.
- g) Loosen totally the screws fastening the controls panel and remove it
- h) Loosen the nuts (15) and (9) (See Fig. 7) of the thermocouple you wish to change and remove it.
- i) Assemble the new thermocouple by proceeding in reverse order to what is explained above. Then replace the controls panel and controls.

CHANGING A BURNER

- a) Disconnect the oven from the mains and close the gas supply. **Make sure that the gas supply is closed before you continue with this operation.**
- b) Remove all the valve controls (on the right of the oven) by pulling them outwards. Then remove the top and bottom inter-burner sheets of the burner you wish to change.
- c) Remove totally the screws fastening the controls panel and remove it
- d) Remove totally the screws fastening the rear panel and pull it towards the left to remove it
- e) Remove the tube (12) and thermocouple (13) (See Fig. 11) corresponding to the valve of the burner you wish to change by loosening the nuts (11) and (14).
- f) Pull the elbow piece (8) outwards to remove the Venturi burner. Totally loosen the screws fastening the burner (16) to its support (17).
- g) Replace the burner and assemble the new one in its support.
- h) Proceed in reverse order to what is explained above to assemble it. **MAKE SURE** there are no gas leaks. Replace the panels and do not forget to adjust the minimum of the burner.




Fig 11

APPENDIX A

List of spare parts that may require changing. Electric diagram.

Denomination	Code
Burner	030001
Safety valve	030112
Safety valve bracket	030113
Klingerit valve washer	030114
Thermocouple of 350 mm	030115
Valve coil	030116
Butane/Propane injector (28-30 mbar)	030117
Natural Gas injector	030118
Motor reducer 220V	020112
Simple switch	06004
Double switch (ovens with light)	060006
Quartz light (ovens with light only)	010013
Spit without skewers	0500001
Simple Skewer (without screw)	050107
Double Skewer	050110
Skewer screw	050116
Spit handle	050112
Hook for removing spits	050114
Oven glass, model. RVG/2-CM	040205
Oven glass, model. RVG/3-CM	040305
Oven glass, model. RVG/4-CM	040405
Oven glass, model. RVG/6-CM RVG/112-CM	040605
Oven glass, model. RVG/8-CM RVG/152-CM	080805

APPENDIX B

GAS TYPES AND PRESSURES
GASKATEGORIE UND GASDRUCK
CATEGORIES ET PRESSIONS GAZ
CATEGORIAS Y PRESIONES DE GAS
GASTYPES EN GASDRUK

AT	20 - 50	II2H3B/P
BE, FR	20/25 - 28/37	II2E+3+
DE, LU	20 - 50	II2E3B/P
DK	20 - 30	II2H3B/P
ES , GB, GR, IE, CH	20 - 28/37	II2H3+
EE, FI, LT, LV, NO, RO, SI, BG, SE, HR, TR	20 - 30	II2H3B/P
IT, CZ, PT, SK	20 - 30/37	II2H3+
NL	20 – 30/37	II2EK3B/P
HU	25 - 30	II2HS3B/P
PL	20 - 37	II2E3B/P
MT, CY	30	II3B/P

TECHNISCHE INFORMATIE - GASOVENS

MODEL MODELO MODELE MODELL MODEL	Length x Depth x Height Largo x Ancho x Alto Largueur x Prof. x Haut Länge x Breite x Höhe Lengte x Breedte x Hoogte	WEIGHT PESO POIDS GEWICHT	GAS GAS GAZ GASTYPE	PRESSURE PRESION PRESSION DRUCK DRUK	FLOW CONSUMO CONSUPTION VERBRAUCH VERBRUIK	POWER Hi POTENCIA Hi PUISSANCE Hi LEISTUNG Hi VERMOGEN HI
RVG/2-CM	1098 x 480 x 640	66 Kg	G30	28/30/50	0,94 Kg/h	11,8 Kw
			G31	30/37/50	0,76 Kg/h	10,4 Kw
			G20	18/20	1,30 m3/h	12,4 Kw
RVG/3-CM	1098 x 480 x 820	86 Kg	G30	28/30/50	1,41 Kg/h	17,7 Kw
			G31	30/37/50	1,15 Kg/h	15,6 Kw
			G20	18/20	1,95 m3/h	18,6 Kw
RVG/4-CM	1098 x 480 x 1000	103 Kg	G30	28/30/50	1,88 Kg/h	23,6 Kw
			G31	30/37/50	1,52 Kg/h	20,8 Kw
			G20	18/20	2,60 m3/h	24,8 Kw
RVG/6-CM	1098 x 480 x 1860	170 Kg	G30	28/30/50	2,82 Kg/h	35,4 Kw
RVG/112-CM	1098 x 660 x 1860	204 Kg	G31	30/37/50	2,30 Kg/h	31,2 Kw
			G20	18/20	3,90 m3/h	37,2 Kw
RVG/8-CM	1098 x 480 x 1920	193 Kg	G30	28/30/50	3,76 Kg/h	47,2 Kw
RVG/152-CM	1098 x 660 x 1920	230 Kg	G31	30/37/50	3,04 Kg/h	41,6 Kw
			G20	18/20	5,20 m3/h	49,6 Kw

BURNER INJECTORS INJECTORES DE QUEMADOR CHICLERS DU BRULEUR DÜSEN DER BRENNER INJECTOREN VAN DE BRANDERS

Gas	Druk	Diameter
Butaan	28/30/50 mbar	1.20
Propaan	30/37/50 mbar	1.20
Aardgas	18/20/25 mbar	1.90

Note: The diameter of the injectors is indicated on their casing (mm)

Nota: El diámetro de los inyectores va marcado en los mismos (mm)

Nota: Le diamètre des injecteurs est inscrit sur les injecteurs mêmes (mm)

Anmerkung: Der Durchmesser der Düsen ist an denselben gekennzeichnet (mm)

Opmerking: De diameter van de injectoren staat op de injectoren zelf (mm)